

Azek Pavers Info

More Information visit: <http://www.azek.com/products/pavers/>

Best Advice for Cleaning Azek Pavers


AZEK Pavers require virtually no maintenance other than occasional replenishment of joint sand and any necessary clean-up from spills.

- Most surface spills and stains can be cleaned using household cleaners and warm water.
- Chemical spills (e.g. petroleum, paint) should be cleaned as soon as possible with an appropriate industrial cleaner and rinsed thoroughly with water. Chemical spills or stains left untreated over long periods of time may degrade the surface finish and integrity of the product and are not covered under warranty.
- AZEK Pavers can be cleaned using a pressure washer. Be sure to use a wide fan and keep tip far enough away from the surface to not score the product.
- Always check the compatibility of cleaning products with plastics and rubber prior to using on AZEK Pavers.

How many Pavers will I need?

MEASUREMENTS length x width = sq. ft.	REQUIRED NUMBER OF GRIDS		
	SINGLE COLOR BLEND	TWO COLOR BLEND	THREE COLOR BLEND
50 sq. ft.	29 grids	30 (15 of each color)	30 (10 of each color)
100 sq. ft.	57 grids	58 (29 of each color)	57 (19 of each color)
250 sq. ft.	141 grids	142 (71 of each color)	141 (47 of each color)
500 sq. ft.	282 grids	282 (141 of each color)	282 (94 of each color)

Paver Pattern Ideas




Here is how the grids must be orientated to assure overlap in all directions for other patterns:

Herringbone:


This is the most popular and easiest to install pattern. Pavers will interlock grids in both directions.

- Lay the installation grids as illustrated at left.
- Start laying pavers at the starting corner.



Plain Weave:


- 8 x 8 - 57.1%
- 4 x 8 - 28.6%
- 4 x 4 - 14.3%
- Lay the installation grids as illustrated at left.
- Start laying pavers at the starting corner.
- Compatible with 4" and 8" soldier course borders.



Basketweave:


This is the simplest installation method for a Basketweave pattern, but it will require extra installation grids. (Visit <http://www.azek.com/idea-starters/pavers-patterns.aspx> to learn how to install without extra grids)

- The starting paver must be laid 4" down and 4" over from the top left corner of the grid. This will shift the pattern over and assure at least one paver will connect two grids in both directions.
- The leftover grid can either be trimmed off, or a 4" border can be used to fill in the extra space.



Block Lattice:


- 8 x 8 - 44.4%
- 4 x 8 - 44.4%
- 4 x 4 - 11.1%
- Lay the installation grids as illustrated at left.
- Start laying pavers at the starting corner.
- Perimeter 8" x 8" pavers can be replaced with 4" x 8" pavers to create an 8" soldier course border.



Running Bond:

This pattern will require the staggering of grids to assure the pavers will connect them in both directions.

- The starting paver can be laid in the top left corner, but the next column of grids must be staggered halfway down the starting row. Every other column will need one half grid at the top.
- Each half of the cut grid can be used.



Soldiered:

- 8 x 8 - 25%
- 4 x 8 - 50%
- 4 x 4 - 25%
- Trim Grids as illustrated at left.
- All parts of quarter Grids and half Grids can be used.
- Lay the installation grids as illustrated at left.
- Start laying pavers at the starting corner.
- Adding 4" or 8" soldier course would eliminate the need to cut grids.